



## INSTALLATION INSTRUCTIONS

### Grab Rails



## INSTALLATION INSTRUCTIONS

1. Measure site to find correct location for Grab Rail(s) ensuring it is installed to meet disabled code AS1428.1-2009 (Amdt. 2010) and local building codes.
2. Mount the concealed mounting flanges to the wall using wall fixings (Supplied by others) where required.
3. Slide covers over mounting flanges ensuring raised edges of the flange are lined up with dimples of the bracket cover. Press into place.

**Warning:** Grab Rails are no stronger than the anchors or walls to which they are attached, and therefore, must be firmly secured in order to support the loads for which they are intended.

### Notes

**Ambulant compliant:** Ensure that relevant sections of AS1428.1-2009 (Amdt. 2010) are consulted before installing Grab Rails.

## SPARE PARTS

**RBA4110-999-002** Handset, slider and hose complete (for showers only)

## ASSOCIATED PRODUCTS

Product	Description
<b>RBA4000-Antiligature</b>	Anti-Ligature Grab Rails
<b>RBA4150-Series</b>	Backrests
<b>B819687</b>	Folding Shower Seat
<b>RBA4300-Series</b>	Tactile Signs
<b>RBA1211-600</b>	Sensor Tap

Please visit [www.rba.com.au](http://www.rba.com.au) from AUS, or [www.rbagroup.co.nz](http://www.rbagroup.co.nz) from NZ.



For further information,  
contact the nearest RBA Group office:  
**SYDNEY • MELBOURNE • BRISBANE • PERTH • AUCKLAND**  
Australia 1300 788 778 | [www.rba.com.au](http://www.rba.com.au)  
New Zealand 0800 722 111 | [www.rbagroup.co.nz](http://www.rbagroup.co.nz)

