

## INSTALLATION

1. Measure up site to find correct location for shower rail. Provide concealed anchor device or backing as specified or required in accordance with local building codes before wall and ceiling are finished.
2. Mount the track sockets to wall using two screws and the single point hanger to the ceiling in required location.
3. Attach single point hanger to rail in corresponding location.
4. Insert hooks into slot and mount the rail, attaching suspension rod.
5. Screw the rail and suspension rod to the mounting brackets (Concealed anchor devices and mounting screws furnished by others).

## SPARE PARTS

RBA4177 999 003	Aluminium Wall Mount x 2
RBA4177 999 004	Aluminium Hanger Rod x 1m
RBA4177 999 005	Plastic Swivel Curtain Hooks x 12
RBA4177 999 006	Aluminium Single Point Hanger x 12



For further information,  
contact the nearest RBA Group office:  
SYDNEY • MELBOURNE • BRISBANE • PERTH  
Phone: 1300 788 778 • Fax: 1300 788 878  
info@rba.com.au • www.rba.com.au



## INSTALLATION INSTRUCTIONS

### ALUMINIUM SHOWER CURTAIN RAIL

**Suits:**  
**RBA4177 Series**

